

PacketCheck™ is licensed either through software licensing or USB hardware dongle. Follow the procedures below as per your purchase order.

System Requirements

- Windows® 10 and above Operating System (**64 bit Only**).
- Core i3 to i7 (or equivalent), 4 GB Memory, 2 x NIC cards, and USB Ports.
- PCs which include GL hardware/software require Intel or AMD processors for compliance.



Note:

- Ensure that the **Anti-Virus** and **Windows Firewall** programs are disabled or configure PacketCheck™ Application as a trusted. This will help ensure uninterrupted functionality by avoiding any disruptions from security measures.

Software Based Licensing (for evaluation only)

- In case of software-based licensing, the software executables, license installer, and documents can be downloaded from the software licensing web portal (refer to email notification from GL Communications).
- Follow the instructions in the <https://www.gl.com/ses/download/GL-Software-License-Evaluation-Instructions.pdf> to install software license.
- To verify that the purchased licenses are installed correctly, open any web browser from the system on which the software license is installed and type the URL "<http://localhost:1947/int/products.html>". Click on **Features** and confirm that the following **Product licenses** are listed
 - ETH100 (PacketCheck)


USB Dongle Based Licensing

- If the software is licensed through hardware USB dongle, the shipment will contain a **USB Installation Stick** (pen drive) with necessary software executables, license installer, and documents along with USB Dongle.
- Plug-in the dongle to the USB port of the computer.
- Plug-in the USB Installation Stick (pen drive) to the PC.
- Navigate to \GL-Dongle-LicenseInstaller folder in installation USB stick and **execute GLLdkDongleLicenseInstaller_x64.exe**. Follow the on-screen instructions to complete the installation.
- A **Red** light should appear on the dongle indicating that it is functioning correctly.
- User can verify if the required licenses are installed. Navigate to **C:\Program Files\GL Communications Inc\GLDONGLE** directory, execute **appl_list.exe** and confirm that the following licenses are listed.
 - ETH100 (PacketCheck)
- For any issues during the installation, follow hardware dongle licensing procedure mentioned in the <https://www.gl.com/Brochures/Brochures/Installation-Instructions-for-Dongle-Programs.pdf>.


Warranty License Installer

Follow the below steps to install the Warranty license.

- Navigate to root directory in **USB installation stick** (pen drive) to **Warranty_LicenseInstaller** folder, execute **GLSupportWarrantyLicenseInstaller.exe**. Follow the onscreen instructions and complete the installation.



- To confirm that warranty is installed properly, double-click on Warranty Application List icon . This will display the list of warranty applications which are purchased. Refer to the below screenshot.




- In the **Version** column, verify the warranty expiry date to be as expected (depending on the support warranty purchased).

 **Note:**

- Any latest software updates after warranty period will not be available until warranty licenses are renewed.

Software Installation

- Navigate to folder **ETH100-ETH200-PacketCheck\PacketCheck-Software-verXX** in installation USB stick. Right-click **PacketCheckx64.exe** (for 64-bit OS) and select **Run as Administrator**.




Invoking Application


- It is recommended to reboot the system after the software installation.




- Double click on PacketCheck™ shortcut icon created on the desktop. The application should invoke without any errors.
- The **PacketCheck Initial config** window appears as shown below.



- It is necessary to perform initial configuration to get started with the application.
- Under **Mode Selection**, select **Normal Mode** option and click on **Start PacketCheck** to get to the main PacketCheck GUI as shown below.





- This completes the successful installation of PacketCheck™ application.
- For quick functional verification, refer to **PacketCheck-Quick-Verification-Guide**.