

The VQuad™ Script Editor is automatically installed with VQuad™ and can be invoked within VQuad™.

The manual installation is available only if you wish to install and run VQuad™ Script Editor on a system where VQuad™ is not running.

The VQuad™ Script Editor software requires only software installation procedure. VQuad™ Script Editor software does not require Hardware Dongle or any licenses to be installed.

Pre-requisites

- PC Requirements – Windows® 7 or Higher OS (32 bit or 64 bit).
- Minimum CPU Requirements – Core i3 to i7 (or equivalent), 4 GB Memory, USB 2.0 Ports.

Step 1: VQuad™ Script Editor Software Installation


- Plug-in the **USB Installation Stick** (pen drive) to the PC. This is provided with the shipment package by GL Communications.
- Run the **GLVQuadScriptEditor.exe** executable from the installation USB stick (\VQuad-VQT\VQT010-VQT270-VQT241-VQuad-Related-Items\VQT010-VQuad-Software-verXX) in **Run as Administrator** mode.
- Follow the on-screen instructions to complete the VQuad™ Script Editor software installation.
- The software gets installed in 'C:\Program Files\GL Communications Inc\VQuad' directory (or 'C:\Program Files (x86)\GL

Communications Inc\VQuad' directory in 64-bit Windows® OS) and creates a shortcut icon  on the desktop.

- It is recommended to reboot the system after the software installation.

Step 2: Quick Check-out Procedure

To verify the software installation, perform the following steps:

- To invoke the Script Editor application, right-click on the Script Editor icon  created on the desktop and choose to **Run as Administrator**.
- From **File** menu, select **Open** and browse to VQuad™ installation directory (C:\Program Files (x86)\GL Communications Inc\VQuad) to open a sample VQuad™ script (*.scp) as shown below.

